


IS-Talk Tech Support Doc: Sonicwall Firewall Modification

Page 1 of 2 REV: 06.03.21

4900 Cahaba River Road Vestavia, Alabama 35243 205.314.8800

www.is-talk.com

- 1. Login into Sonicwall Firewall
- 2. Firewall Access Rules:



3. Firewall Settings (Flood Protection):

Layer 3 SYN Flood Protection - SYN Proxy

SYN Flood Protection Mode:	Watch and report possible SYN floods	•
SYN Attack Threshold:		
Suggested value calculated from gathered statistics:	192	
Attack threshold (incomplete connection attempts / second): SYN-Proxy options:	300	
All LAN/DMZ servers support the TCP SACK option		
Limit MSS sent to WAN clients (when connections are proxied)		
Maximum TCP MSS sent to WAN clients:	1460	
Always log SYN packets received		

4. VOIP (Enable consistent NAT):

General Settings

Enable consistent NAT

SIP Settings

- Use global control to enable SIP Transformations
 Use firewall Rule-based control to enable Enable SIP Transformations
 Enable Transformations on TCP connections
- 5. ***If the phone's quality is poor, it may be caused by the Sonicwall Firewall DPI inspection.

Try "Maximum SPI Connections (DPI services disabled)"***

